



Synthetic Decking Maintenance



EASY-TEK / TEK-DEK does NOT require special maintenance:

Normal pollution and spillage will NOT go in to the PVC !
It will stay on the surface and can be easily removed !

Cleaning by wiping or rinsing:

Dry sand and dirt can easily be removed with a firm brush or a broom.



Spillages of food and drinks can be simply removed by rinsing with water.

If necessary, a mild detergent can be used for “sticky” spills.



Do NOT use any “chemical” additives or cleaners!

Scrubbing or powerwash:



If long term –air- pollution or waterstains occurs, you can apply a high pressure waterhose or power cleaner to rejuvenate your EASY-TEK / TEK-DEK.

Scraping or sanding:

For really big “problems” like spilled paint or even cigarette burns;
Use a 40 grit sandpaper and **BY HAND**,
rub down the stain in the direction of the woodgrain.



NEVER use any sanding (power) tools !

When in doubt: contact your **EASY-TEK / TEK-DEK** supplier !
They are **ALWAYS** able to help you in these matters !!

UV stable, low maintenance hard wearing and non slip...
However;
it's not completely indestructable:

Please avoid chemicals like:

Bleach, acetone or paint-thinners !!!
Check soaps and shampoo for chemical ingredients!

In some cases it **CAN** dissolve the PVC and leave a mark.

When accidentally damaged –no matter how badly -,

please contact your **EASY-TEK / TEK-DEK** supplier, and they **CAN** help you !

WWW.EASY-TEK.COM

